


# NAVAL FORCES



Phot: Jørgen Eide / Brunvoll AS

## Load and Force

- Loadcells, wide range, subsea included
- Safe load protection
- Tensiometers for static and running line
- Torque measurement
- Load data logger



Tensiometers

## Sensors

- Accelerometers
- Vibration sensors
- Position sensors
- Liquid Level sensors
- Pressure sensors
- Water in oil sensors
- Oil debris sensors
- RPM speed
- Distance sensors



Oil debris monitoring

## Electronics & Condition

- In Vibration analysis systems
- Multi sensor connections
- Instrumentation
- Vibration signal condition
- Sensor signal condition
- Converters
- Data collection (vibration)
- Indicators



Vibration data collection

## Brunvoll Components

Roy Dahl / rd@brunvoll.no  
+47 959 00 734

Jørn Jul-Larsen / jjl@brunvoll.no  
+47 948 70 022

www.mar-el.no

