

WATERWORKS



Load and encoders

- Incremental encoders
- Absolute encoders
- Load cells tank/silo weighing
- Compression load
- Load indicators



Magnetic Encoders

Sensors


- Speed sensors
- Water level sensors
- Blackwater level sensors
- Vibration sensors
- Linear position sensors
- Rotary sensors
- Speed sensors



USB prog. Level sensor

Condition monitoring

- Data collection (vibration)
- Vibration analysis.
- Pump vibration monitoring
- Stroboscope
- Load limitation



24/7 pump vibration monitoring



Brunvoll Components

Roy Dahl / rd@brunvoll.no
+47 959 00 734

Jørn Jul-Larsen / jjl@brunvoll.no
+47 948 70 022
www.mar-el.no

